



## Window Film Care

Do not clean for 30 days after installation. This will help secure proper curing of the adhesive system to the glass.

Do not use bristle brushes, abrasive scrubbing sponges or any other cleaning materials that could scratch the film. Always use fresh clean soft materials to wash and dry your window film surfaces.

Common household glass cleaners may be safely used to clean your windows, including Windex and other ammonia based cleaners.

The mounting solution used during the installation of your CoolVu Window Film will require a period of time to dry out. Cold and/or cloudy weather conditions can lengthen the dry out time of these films, while warm weather and direct sunlight exposure will shorten the dry out time.

Small water beads and a slightly cloudy look may appear during the dry out period. If slow drying does occur, do not become alarmed, it is a part of the natural curing.