

# LC PRIVACY FILM

## Care & Maintenance

To preserve and maximize the life of LC Privacy Film, please follow these instructions.

### OPERATING LC PRIVACY FILM

1. LC Privacy Film is **PRIVATE/FROSTED in the default unpowered (OFF) state.**  
LC Privacy Film is **CLEAR/TRANSPARENT\* when in the powered (ON) state.**
2. When Clear/Transparent glass is *NOT* needed, **film should always be in PRIVATE/FROSTED (OFF) state.**

*\*NOTE: LC Privacy Film will never appear 100% clear when powered and there will always be a certain amount of white haze. This is normal and is not considered a material defect.*

### CLEANING LC PRIVACY FILM

1. **WHEN CLEANING, ALWAYS SWITCH FILM TO THE PRIVATE/FROSTED (OFF) STATE.**
2. **Do not clean LC Privacy Film for 30 days after install.**
3. Always use a **soft microfiber cloth with cleaner applied to cloth – DO NOT use a spray bottle** to apply cleaner.
4. **Use a non-ammonia-based cleaner only.**
5. **Never ever use abrasive cleaners.** Scratches will result.
6. **Avoid liquids pooling at bottom of glass or edges of film** to avoid water damage and film failure.
7. **Avoid liquids getting behind the film** as this will affect its adhesiveness and create bubbles.
8. **Do not let liquids or metal come in contact with the copper bus bars.**
9. **Avoid applying pressure to the edges of the film** to mitigate possible damage. If necessary, wipe towards the edges of the film, not away from the edges.
10. **Never ever scrape film with a razor blade** or any sharp objects.
11. **Properly dry the film** using a soft dry lint-free microfiber cloth.
12. **Film should remain in the PRIVATE/FROSTED (OFF) state for one hour after cleaning** to allow it to fully dry.

If you have any questions, please contact us:

Innovative Glass Corp | 120 Commercial Street, Plainview, NY 11803  
(516) 777-1100 | (888) 863-4527 | [info@eGlass.com](mailto:info@eGlass.com)

[www.InnovativeGlassCorp.com](http://www.InnovativeGlassCorp.com)